



- 7** Using a knife, carefully trim away excess braiding materials and inert fabric housing. Take care not to damage or cut the insulation of the internal header cable while removing the excess materials.



- 8** Trim the exposed anode wire back as close as possible to the end of the SPL™-FBR Linear Anode.



- 9** Install anode segment in accordance with the design/ installation requirements.